


- 1. Profile
- 2. Cover
- 3. Hook for a stretch ceiling foil
- 4.1 End cap (item 4.1)
- 4.2 End cap (item 4.2)
- 4.3 Screw (element 4.3)

- Lighting fixture
- FOLED Final end cap (ref. 42652)


*The full range of accessories and electronics is available at www.KlusDesign.eu

NOTE! All LED tapes must be connected to a 12 V or 24 V power supply.


IMPORTANT: Not all possible mounting procedures are presented here. More mounting procedures and related accessories can be found at www.KlusDesign.eu. Drawings of extrusions and accessories in these instructions are simplified and only approximate the actual shapes.



Attach item (4.2) to the profile (1) and mark the drilling locations.




Drill the holes in the profile.



Mount the end cap items (4.1; 4.2) and lock them with the screw (4.3).


IV



Prepare the hook for a stretch ceiling foil (3) to be mounted in the profile and the end cap.


NOTE! To minimize the risk of cutting the foil, protect it with painter's tape or similar item.

V



Mount the hook for a stretch ceiling foil.

VI



Stretch the ceiling foil with heater and mount the cover (2) in the profile.